simactive Running Correlator3D Via Python Scripts QUICKSTART GUIDE

OVERVIEW

Correlator3D (C3D) has been developed to run in both the graphical user interface (GUI) and in command-line mode. The latter gives the user the option to create scripts that can be executed via batch files, through the Python programming language. This method only requires a minimal amount of programming, along with the associated files to execute a processing workflow.

This guide will describe the process of creating a Python script along with the files required to run a project in Correlator3D.

PROJECT SETUP

In addition to C3D, users will need to install Python which can be downloaded from the following address:

https://www.python.org/

Prior to processing, an exterior orientation (EO) file containing the image names and corresponding coordinates (X, Y, Z and possibly omega, phi, kappa angles) is required. If the EO data are stored within the EXIF of the image, an extraction tool such as ExifTool can be used:

https://exiftool.org/

Additionally, a directory structure will be needed to store the input data. In the following example, the name used will be:

E:\SIMACTIVE\Demo_Data\SCRIPT_STANDARD_PROJECT\ REQUIRED_FILES

EXIF EXTRACTION

If EO information is available as a TXT or CSV file, no extraction is needed. If it is stored in the images, the following command line can be used to extract EXIF coordinates from the images:

> Exiftool -T -filename -gpslongitude -gpslatitude -gpsaltitude -n E:\SIMACTIVE\Demo_Data\SCRIPT_STANDARD_PROJECT\I MAGES*.JPG E:\SIMACTIVE\Demo_Data\SCRIPT_STANDARD_PROJECT\ EO.csv

The converted EO file should then be placed in the REQUIRED_FILES folder. Two additional files to be included in that folder prior to processing are:

- Camera calibration file
- C3D Script.spt file

Each can be generated as per the instructions described in the following sections.

CAMERA CALIBRATION FILE

The following figure shows a standard calibration file used by C3D. The values should be modified to match the camera used for a specific project.

	Camera.cam [E:\SIMACT	IVE\Demo_Data\SCRIPT_STANDAR	RD_PROJECT\REQUIRED_FILES] - Notepad3					
<u>F</u> ile	Edit View Appeara	ance <u>S</u> ettings <u>H</u> elp						
	🚔 🗟 📾 🔄 🖘	🤿 📈 🗅 💼 🛍 🧞 🛛	요 🌪 📾 🚓 🖕 🖉 💭 🖂 🔜 🖳					
1	***************************************							
2	SimActive Camera Calibration File							
3	Copyright(c) 2003 SimActive Inc.							
4	All rights reserved.							
5	***************************************							
6	ConfigType	Polynomial						
7	ImageWidth	4000	#Image width (pixels)					
8	ImageHeight	3000	<pre>#Image height (pixels)</pre>					
9	FocalLength	4.730000e+00	#Focal length (mm)					
10	Xmm	0	<pre>#Principal point, width direction (mm)</pre>					
11	Ymm	0	<pre>#Principal point, height direction (mm)</pre>					
12	PixelSize	1.540	<pre>#Pixel size (microns)</pre>					
13	KØ	0.000000e+00						
14	K1	0.000000e+00						

C3D SCRIPT FILE

An example of a script file, which can be modified to fit specific processing requirements, can be found in the following directory:

\Program Files\SimActive\Correlator3D\Sample Files\Script Folder

The C3D_Script.spt file includes all the processing options available in C3D. Users can modify a copy of the file and change values to match processing needs. In the following example, it is called My_Script.spt.

	My_Script.	spt - Notepad	-	- 1		×				
File	Edit	View				٩				
simactive Script File copyright() 2003 Simactive Inc. Generalitingual ation										
	ATFold Camera EOAdju Extrac Imager Inpute TiePoi	ler Calibration stment tionType iltering O ntExtraction	E:\SIMACTIVE\Demo_Data\SCRIPT_STAMDARD_PROJECT\Correlator3D\AT\ Unconstrained UnconstrainedAT Automatic E:\SIMACTIVE\Demo_Data\SCRIPT_STAMDARD_PROJECT\Correlator3D\IE0\Init On	ial\In	itial	.ieo				
DSMGeneration>										
1	Genera InputE Output Resolu VertAc	tePointCloud O DEM tion curacy	Off E:\STMACTIVE\Demo_Data\SCRIPT_STANDARD_PROJECT\Correlator3D\IEO\Step E:\STMACTIVE\Demo_Data\SCRIPT_STANDARD_PROJECT\Correlator3D\DEM\DSM. Coarse Fast	_1\Ste smf2	p_1.i	eo				
	Extractio	n>								
1	InputD Output	EM E:\SIMAC	TIVE\Demo_Data\SCRIPT_STANDARD_PROJECT\Correlator3D\DEM\DSM.smf2 TIVE\Demo_Data\SCRIPT_STANDARD_PROJECT\Correlator3D\DEM\DTM.smf2							
ort	horectifi	cation>								
ĩ	DSMBas InputD InputE Output Overla Overvi Resolu TiledT	ed of EM E: Format Ge ORIFolder E: p Ma ews On tion Op iff Ti	f (SUMACTIVE\Demo_Data\SCRIPT_STANDARD_PROJECT\Correlator3D\DEM\DTN.smf (SUMACTIVE\Demo_Data\SCRIPT_STANDARD_PROJECT\Correlator3D\TEC\Step_1\ OTIFF (SUMACTIVE\Demo_Data\SCRIPT_STANDARD_PROJECT\Correlator3D\Orthos\ ximal timal led	2 Step_1	.ieo					
} ⊲Mos	aicCreati	on>								
{	ColorE Feathe InputO MinNum Mosaic Optimi Output	alancing RIList Blocks Name zeViewAngle Folder	ON 37 51 51 SIMACTIVE\Demo_Data\SCRIPT_STANDARD_PROJECT\Correlator3D\Orthos\St Mosaic ON E:\SIMACTIVE\Demo_Data\SCRIPT_STANDARD_PROJECT\Correlator3D\	ep_1.0	rl					
<dem< td=""><td>T111ng></td><td></td><td></td><td></td><td></td><td></td></dem<>	T111ng>									
	Output	EM E:	<pre>SIMACTIVE\Demo_Data\SCRIPT_STANDARD_PROJECT\Correlator3D\DEM\DSM.smf2 SIMACTIVE\Demo_Data\SCRIPT_STANDARD_PROJECT\Deliverables\</pre>							
	<pre># Either TileDefFile or DEMName + TileEidth + TileHeight + OutputFormat # TileDefFile E:\SIMACTIVE\Demo_Data\SCRIPT_STANDARD_PROJECT\Correlator3D\Mosaic\TileDef.tdf</pre>									
1	# The DEMNan TileWi TileHe Output	following pa le DSM dth 100 right 100 Format Geo	rameters must be specified if TileOefFile is not used 00 00 TIFF # Must be 'GeoTIFF', 'AsciiGrid', 'SMF2Format', 'SMFFormat', # 'Shapefile' or 'LIDARLAS'							
<exp< td=""><td>ortMosai</td><td>></td><td></td><td></td><td></td><td></td></exp<>	ortMosai	>								
1	<pre># The BlockD Mosaic NbBanc Output Mosaic Single Output TiledI Overvi JPEGIr</pre>	name of the efFile Type S Folder Name Tile Format IFF ews TIFF	<pre>file is always "Mosaic.sbd" located in the mosaic output folder. E:SIMATUS/Demo_DataSCRPT_STANAPAGE_MFOIET(Correlator 20/Mosaic/M Standard Automatic # A numerical value is also accepted. E:SIMATUS(Demo_DataSCRPT_STANAPAGE_MOSET(Deliver) E:SIMATUS(Demo_DataSCRPT_STANAPAGE) 0 # 000 *</pre>	osaic. ed.	sbd					
Ln 1	Col 1		70% Windows (CRLF) U	JTF-8						
						-				

CREATING THE PYTHON SCRIPT

Once the extracted EO, the camera calibration file and the C3D_Script.spt files have been created and placed in the REQUIRED_FILES folder, a Python script can be produced. The following figure shows a sample script file (Python_C3D.py) that is designed to complete the following steps:

- 1. Check if the required folders exist and if not, create them.
- 2. Use ConvertEO (a program included with a C3D installation) to create the project using the provided camera and EO files.
- 3. Check to see if the Deliverables folder exists allowing the export of the mosaic. If not, create this folder.
- 4. Run the C3D script file (My_Script.spt).
- 5. Write the C3D files into the project folder.



PROCESSING

From the command prompt, the newly created Python script (Python_C3D.py) can be simply executed. Once the Script is completed, it will prompt a "Project processed with success" message.

Upon completion, a C3D project file (.c3d format) will have been created, which allows the visualization of the results within the GUI. The template .c3d file located in the REQUIRED_FILES folder can be simply copied and pasted in the Correlator3D folder where the project has been created. Then the project file can be opened in C3D.